

ACS.MET3 LS SAFETY ASSESSMENT CRITERIA INITIAL and RE-ASSESSMENT. LIMITED SCOPE EMERGENCY SERVICE PROVIDER AND GAS METER INSTALLER DOMESTIC GAS METER INSTALLATIONS NATURAL GAS WITH A CAPACITY NOT EXCEEDING 6m³/h

MET3 LS Initial and Re-assessment

Introduction

Tests competence to install and commission domestic sized gas meters which are then sealed off at the meter outlet fitting, ensuring gas is not left available to installation pipework.

CBs may adopt Competence and Criteria numbering different to that used in this document.

CB documentation may adopt wording for criteria different to that used in this document, provided the meaning is unaffected.

Range

Primary meters of badged capacity $\leq 6 \text{ m}^3/\text{h}$.

Pre-requisites

CMA2 LS.

Installation of MP primary meters of badged capacity \leq 6 m³/h requires REGT1 **Exclusions**

Connection of installation pipework downstream of gas meter outlet; commissioning installation pipework and appliances; secondary meters; meter reading; pre-payment mechanisms; meter box installation; construction of meter compartments and housings; gas service pipework; installation or exchange of ECVs; service valves or their operation; exchange or replacement of existing gas meters and their removal from site and subsequent disposal; testing by OFGEM; theft of gas.

References

- HSL56
- BS 6400 -1
- BS 6400 -2
- BS 6891
- IGEM/G/6
- GIUSP.
- IGEM/UP/1b

The References (REF) where indicated are only a guide to where the criteria can be resourced and therefore the REF may not be exhaustive.

ACS.SMB.003.ACDND indicates those Normative Documents that should be held by ACs.

Abbreviations

AC. Assessment centre AECV. Additional emergency control valve CB. Certification Body ECV. Emergency control valve I. Initial LP. Low pressure LS. Limited scope MIV. Meter inlet valve MP. Medium pressure OP. Operating pressure Ref. Reference. R. Re-assessment

PER	FORMANCE CRITERIA	REF	I	R
1a.	determine pressure in gas service pipe as LP or MP		✓	✓
1b.	check ECV/MIV/AECV operates correctly		✓	✓
2.	check meter and installation components are fit for use and purpose and		✓	✓
	regulator has been appropriately set and sealed with manufacturer's mark			
3.	isolate gas supply prior to work		\checkmark	\checkmark
4.	correct use temporary electrical equipotential bonding		✓	\checkmark
5.	remove plug/cap from ECV/MIV/AECV		\checkmark	\checkmark
6.	connect meter, ECV/MIV/AECV and regulator		✓	✓
	via bracket, pliable connection, fittings and new washers			
7.	seal meter outlet		\checkmark	\checkmark
8.	re-establish gas supply		\checkmark	\checkmark
9.	check work carried out is gas tight		\checkmark	\checkmark
10.	purge meter		\checkmark	\checkmark
11.	check regulator OP using a meter regulator check device (19 to 23 mbar)		✓	\checkmark
11b.	check regulator locks up at a pressure not exceeding 30 mbar with no gas is		\checkmark	✓
	flowing			
12.	break seal, re-set regulator (if necessary) and re-seal regulator		~	~
13.	apply appropriate labels and notices		✓	\checkmark
14.	explain operation and use of ECV/MIV/AECV		✓	
	Identify and options founds on values controls filters requilators		✓	\checkmark
15.	Identify gas safety faults on valves, controls, filters, regulators		~	✓
KNO	WLEDGE AND UNDERSTANDING	REF	I	-
KNO		REF		✓ ✓
KNO 1	WLEDGE AND UNDERSTANDING Incorrect meter locations	REF	I ✓	-
KNO	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated	REF		✓ ✓
KNO 1 1b 1c	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion	REF		✓ ✓ ✓
KNO 1 1b 1c 1d	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections	REF		✓ ✓
KNO 1 1b 1c 1d 2.	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter	REF		✓ ✓ ✓ ✓
KNO 1 1b 1c 1d	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections	REF		✓ ✓ ✓
KNO 1 1b 1c 1d 2. 3.	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter volume of gas passed by a meter U6 m3/h to effect a satisfactory purge	REF		✓ ✓ ✓ ✓
KNO 1 1b 1c 1d 2. 3.	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter	REF		✓ ✓ ✓ ✓
KNO 1 1b 1c 1d 2. 3.	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter volume of gas passed by a meter U6 m3/h to effect a satisfactory purge	REF		✓ ✓ ✓ ✓ ✓
KNO 1 1b 1c 1d 2. 3. 5. 6.	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter volume of gas passed by a meter U6 m3/h to effect a satisfactory purge meters supplying mobile dwellings and boats ECV/MIV/AECV requirements when meter is installed remotely from dwelling	REF		✓ ✓ ✓ ✓
KNO 1 1b 1c 1d 2. 3. 5. 6.	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter volume of gas passed by a meter U6 m3/h to effect a satisfactory purge meters supplying mobile dwellings and boats	REF		✓ ✓ ✓ ✓ ✓
KNO 1 1b 1c 1d 2. 3. 5. 6. 7.	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter volume of gas passed by a meter U6 m3/h to effect a satisfactory purge meters supplying mobile dwellings and boats ECV/MIV/AECV requirements when meter is installed remotely from dwelling where primary meters serving different parts of a building are grouped together	REF		✓ ✓ ✓ ✓ ✓
KNO 1 1b 1c 1d 2. 3. 5. 6. 7. 8.	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter volume of gas passed by a meter U6 m3/h to effect a satisfactory purge meters supplying mobile dwellings and boats ECV/MIV/AECV requirements when meter is installed remotely from dwelling	REF		✓ ✓ ✓ ✓ ✓
KNO 1 1b 1c 1d 2. 3. 5. 6. 7. 8. 9.	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter volume of gas passed by a meter U6 m3/h to effect a satisfactory purge meters supplying mobile dwellings and boats ECV/MIV/AECV requirements when meter is installed remotely from dwelling where primary meters serving different parts of a building are grouped together safety notices and labels (relating to LS meter installations)	REF		✓ ✓ ✓ ✓ ✓ ✓
KNO 1 1b 1c 1d 2. 3. 5. 6. 7. 8. 9. 10.	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter volume of gas passed by a meter U6 m3/h to effect a satisfactory purge meters supplying mobile dwellings and boats ECV/MIV/AECV requirements when meter is installed remotely from dwelling where primary meters serving different parts of a building are grouped together safety notices and labels (relating to LS meter installations) Recognise unsafe meter installations. HSL56:	REF		✓ ✓ ✓ ✓ ✓ ✓
KNO 1 1b 1c 1d 2. 3. 5. 6. 7. 8. 9. 10. (i)	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter volume of gas passed by a meter U6 m3/h to effect a satisfactory purge meters supplying mobile dwellings and boats ECV/MIV/AECV requirements when meter is installed remotely from dwelling where primary meters serving different parts of a building are grouped together safety notices and labels (relating to LS meter installations) Recognise unsafe meter installations.			✓ ✓ ✓ ✓ ✓ ✓
KNO 1 1b 1c 1d 2. 3. 5. 6. 7. 8. 9. 10. (i) (ii)	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter volume of gas passed by a meter U6 m3/h to effect a satisfactory purge meters supplying mobile dwellings and boats ECV/MIV/AECV requirements when meter is installed remotely from dwelling where primary meters serving different parts of a building are grouped together safety notices and labels (relating to LS meter installations) Recognise unsafe meter installations. HSL56: Reg.9 Emergency controls 9 (1), (2),(4)	REF		✓ ✓ ✓ ✓ ✓ ✓
KNO 1 1b 1c 1d 2. 3. 5. 6. 7. 8. 9. 10. (i)	WLEDGE AND UNDERSTANDING Incorrect meter locations Permission requirements for meters & regulators when relocated Semi concealed meter box installations and the use of 2 a pliable connectors-ion Installation requirements for Meters , Regulators and pliable connections Requirements for determining the maximum capacity of a meter volume of gas passed by a meter U6 m3/h to effect a satisfactory purge meters supplying mobile dwellings and boats ECV/MIV/AECV requirements when meter is installed remotely from dwelling where primary meters serving different parts of a building are grouped together safety notices and labels (relating to LS meter installations) Recognise unsafe meter installations. HSL56:	REF	$ \begin{array}{c} \mathbf{I} \\ \mathbf{V} \\ \mathbf$	✓ ✓ ✓ ✓ ✓ ✓